

LNER / BR CLASS A3 4-6-2



Step 1
Unsolder the cylinder pipes from the rear of the front steps. Hold away from the steps with tweezers.



Step 2
Remove centre screw on front bogie.



Step 11
Carefully lift chassis out of body, taking care with cylinder drain cock pipes.



Step 12
To allow chassis to free-wheel, unsolder wires to motor and remove both screws. This picture shows all the component parts in sub-assembly.



Service Department
Bachmann Europe PLC,
Moat Way, Barwell, Leicestershire, LE9 8EY
Telephone: 0870 751 9990
www.bachmann.co.uk



Step 3
Remove screw and washer carefully.



Step 4
Remove bogie and locate small washer which sits under the bogie.



Step 5
Put the spring and two washers back in order and secure in place with screw.



Step 6
Remove both big screws either side of pivot from front of chassis.



Step 7
Remove rear screw on the Cartazzi truck.



Step 8
Remove front screw on the Cartazzi truck.



Step 9
Lift Cartazzi truck out of chassis being careful with spring and washer.



Step 10
Remove both large screws at rear of chassis.